



**Information & operations manual for
Bavaria 50 2009
'State of Play'**

Welcome



Welcome to Horizon Yacht Charters and your Bavaria 50 "State of Play". We hope you had a pleasant journey and are looking forward to a fantastic holiday and some of the finest sailing in the world here.

This manual is here to guide you through the operation of your yacht. Please take the time to read this manual and don't hesitate to ask any of our professional, friendly staff if you have any questions.

All of the yachts in the Horizon fleet are maintained to the highest standards so that you may enjoy a trouble free vacation, on a beautiful yacht. Please remember that these yachts are all privately owned and we ask that you care for it like it was your own.

Best wishes for a great vacation,

Sylvia and Andrew
Directors

Office Hours:

Monday – Sunday 08:30 – 17:30


Telephone: (284) 494 8787

Duty Manager: (284) 542 8787 (Emergency Only)

Contents

1. Yacht specifications
2. 12 volt panel and 110 volt breakers
3. The inverter panel
4. Engine start procedures
5. Daily engine checks
6. Instruments
7. VHF radio
8. Charging your batteries
9. Anchoring and using the windlass
10. Picking up a mooring buoy
11. Bilge pumps
12. Fresh water systems
13. Heads
14. Showers
15. Refrigeration
16. Using the stove and propane
17. The BBQ
18. Fire safety
19. The dinghy and outboard
20. Operating the generator
21. Using the air conditioning system

1. Yacht specifications



Length	50' 5"
Beam	14' 7"
Draft	7'
Fuel	85 gallons
Water	210 gallons
Engine	72 hp Volvo

Location of:

- Fresh water refills (port transom and by the anchor locker)
- Diesel refill (starboard transom)
- Manual bilge pump (port transom)
- Propane tank (at port helm)
- Windlass breaker (behind 12v panel)
- Diesel cut off valve (starboard aft cabin, below the berth)
- Fridge drain (switch on 12v panel and button above the small fridge)
- Water tanks change over valve (next to the holding tank, aft head)

2. 12 volt panel

Use this button to check battery voltage and water tank status



Functions of the 12 volt panel:

- Top row, from left to right:
- Compass light
- Navigational instruments
- Stereo
- Anchor windlass
- Primary bilge pump (leave this 'off' for the automatic float switch to operate)

Middle row, from left to right:


- Fresh water pump
- Shower drain
- Panel light
- Not in use
- Refrigerator

Bottom row, from left to right:

- VHF/GPS
- Cockpit light
- LPG solenoid
- Fridge drain
- 2nd bilge pump

To the right of the 12v panel is a diagram of a boat and the corresponding light switches. Note that the forward cabin light switch also operates the forward cabin fans.

The 110v Panel:



The 110v outlets will work when plugged into shore power and when using the inverter (see next page).

3. Inverter


When plugged into shore-power, the “AC in” and one of the three inverter status lights will be illuminated in the status bar. The “charge” light will also be illuminated. Before un-plugging from the dock power, press the charge button on the panel and switch off all the breakers on the 110V panel, (see previous page), as well as the breaker on the dock power outlet. Do this process in reverse when plugging into dock power.

To use the inverter:

1. Start the yacht's engine; bring the rpm up to 1400.
2. Press the “invert” button under the control section of the panel. The green light on the switch will then illuminate.
3. On the 110V panel, switch on the main and outlet breakers; leave the heater switch off.
4. All of the 110V outlets are now live.
5. Reverse steps 1, 2 & 3 to switch off the inverter, but run the engine for ten minutes before switching it off.

Always ensure that you have switched the inverter off by checking that the switch on the panel is no longer illuminated. Leaving the inverter on will cause your batteries to rapidly lose their charge.

Invert button



4. Engine start procedures.

- Make sure engine is in neutral.
- Press the glow button for 5 seconds.
- Press the ignition switch then press the start button until you hear the engine running.
- When the engine is running check you have water coming out of the exhaust.
- To stop the engine press the stop button until the engine has stopped.



Should you hear an engine alarm during operation, check which light is on and immediately shut down the engine-CALL HORIZON


All our yacht engines run with diesel fuel. There is a diesel filler cap on the transom which is clearly marked "DIESEL".... DO NOT PUT WATER IN HERE.

5. Daily Engine Checks

- Check the oil level using the yellow dip stick located to the left rear of the engine. The level should be at least halfway between the empty and full marks. To add oil open the oil filler cap on the top of the engine.
- On the right of the engine is the engine coolant reservoir. Open the filler cap to check the coolant level.
- Check for any engine leaks or bilge water below engine.
- Check the fan belt for any damage and correct tension.

KEEP HANDS CLEAR OF ALL MOVING PARTS.

ANY PROBLEMS CALL HORIZON



6. Instruments

Located at the helm 3 Raymarine ST60 instruments:



ST60+ Tridata

ST6002 Autopilot

ST60+ Wind Indicator

Located at the nav station is a Raymarine chart plotter.

7. VHF Procedures

Using the VHF radio:

Familiarise yourself with the method for switching channels, and with the squelch and volume controls on your radio. Most radios have a button to instantly select Channel 16 – ensure you understand how this operates or you could end up speaking on Ch. 16 when you think you are on some other channel.

1. Make sure the radio is switched on, volume quite high, power to high unless the station you are calling is very close.
2. Squelch up until loud hissing, and then back a little until the noise *just* stops.
3. Select the channel for calling (Channel 16, unless specified otherwise).
4. Press switch on microphone when speaking. Release immediately.

If no response then wait two minutes and repeat the call. If still no response, wait a further two minutes before trying again. If calling on Channel 16, it is very important to switch to a working channel after the contact is established. Do not use Channel 16 for your conversations – this channel is for hailing and distress only.

Channels to use:

- 16 Hailing and Distress
- 74 Contact Horizon Yacht Charters (when in range)
- 12 Yacht Charter Companies working channel – assigned for yacht breakdown servicing and emergency only
- 68 Marinas and Yacht Clubs – for lunch/dinner reservations etc
- 06 Ship to Ship – along with Channel 68 and 77 can be used for contact between boats

In the event that your vessel is involved in a non-life threatening incident with an object or with another vessel, it is important that you contact the Horizon Office immediately at 494 8787 or 496 0653. Please remember to get as much information as possible about your location, the other vessel's description and what damage has been done to your vessel so that we can best assist you.

Failure to report any accidents or incidents in a timely manner may result in nullification of your hull damage insurance.

Types of emergency:

In the unlikely event that you are involved in an emergency stay calm and follow these steps. You will also have an Emergency Procedure card next to your VHF.

Distress: "MAYDAY, MAYDAY, MAYDAY." This is an International Distress signal and an imperative call for assistance. It is used only when a life or vessel is considered to be in grave and imminent danger.

Mayday Relay: used to summon help for a vessel which is either too far offshore to contact the coastguard directly, without radio capabilities or whose radio has been damaged or destroyed.

Urgency: "PAN-PAN, PAN-PAN, PAN-PAN" This is the International Urgency Signal and is used when a vessel or person is in some jeopardy but is not considered to be in grave and imminent danger.

Medical emergency: "PAN-PAN MEDICO, PAN-PAN MEDICO, PAN-PAN MEDICO" (Pronounced med-ick-oh). This is an International Urgency Signal that should be used when medical advice is needed.

Safety: "SECURITE, SECURITE, SECURITE" (Pronounced Say-cure-it-tay). This is an International Safety Signal and is a message about some aspect of navigational safety or a weather warning.

How to issue an emergency message

Select Channel 16 and press transmit button on handset

Say slowly and clearly '**MAYDAY, MAYDAY, MAYDAY, CALLING ALL STATIONS**

This is.... (vessel name)....' and repeat vessel name 3 times

Give position – vessel's position in degrees of latitude and longitude or nautical miles from, and bearing to, a navigational landmark

Describe emergency – list the problem, the type of assistance needed; number of passengers aboard (boat length, hull colour and type is also useful)

Repeat '**MAYDAY, MAYDAY, MAYDAY'**

Wait 1 minute for a response, repeat message

ALTERNATIVELY: Dial either 767 or 999 from any BVI cell phone or call 494- HELP (4357)

8. Batteries

The systems on your yacht are all 12volt. The batteries will need to be recharged as often as you deplete them. Conserving power will result in less time needed for charging, so turn off systems that you are not using.

Your batteries will charge when the engine is running at 1400rpms or more, whether sitting at a mooring or motoring to a destination.

- Check the battery levels and make note of them before charging.
- Run the engine at 1400rpms or more for 1-1 1/2hrs.
- Shut the motor off. Wait 15 minutes before checking the battery levels, (directly after turning off the motor they will remain in an excited state for about 10 minutes).
- The House system should come to rest at 12.8 v. and then slowly get lower. When the system gets to 12.2 you should start planning to re-charge the batteries soon.

• Exit Strategy has two battery systems which are isolated from each other, the house batteries have a capacity of 430Ahrs

The batteries are located beneath the aft seat on the port side of the saloon.



9. Anchoring & the windlass

Setting your anchor:

Preparation:

- Establish a non verbal communication system from bow to stern, as with the noise of the engine and wind, verbal communication proves difficult.
- Tie the dinghy painter close to the boat at the bow or amidships to avoid wrapping it around the prop.

Location:

- Choose a clear area to anchor in, normally in 12 to 25 feet. A white bottom is sand and perfect for anchoring. A brown or green bottom will be grass, rock or coral. **Only anchor in sand.**
- Make sure that you are not on a lee shore; i.e. that the land mass is protecting you from the elements and that you are not being pushed onto the shore. **A lee shore is the most dangerous place to anchor your yacht.**

Action:

- Manually lift the anchor over the bow roller and feed the chain so the anchor is just above the water surface.
- Use the elements; approach from down wind or current, whichever prevails.
- Once the yacht is stationary use the electric windlass to drop the anchor. The elements will push you back and away from the anchor.
- Minimum scope is 5:1. In heavy weather you may want to increase that, always ensuring your swing area is clear of any obstacles.
- Engage reverse, slowly building up to 1500 rpm to really drive your hook into the sand.
- Once set, put the engine in neutral and allow the yacht to settle, take transits around the bay to ensure you are not dragging, it is always advisable to snorkel the anchor and ensure it is bedded in correctly and not just lying on its side.

Attaching the snubbing line:

- Once you are happy that the anchor is set you must attach the snubbing line. The snubbing line protects the windlass and it is important that you attach the snubber every time you set the anchor.
- Attach the hook around the chain link (the hook is too big to go through the link) and cleat off the bitter end of the line to a bow cleat. Pay out enough chain so that the snubbing line becomes taut.
- If the hook falls off the chain it means that there is not enough tension on the line. In this case re-attach the hook and pay out more chain until the line is once again taut.

Setting a secondary anchor:

- If a second anchor is required, e.g. you are anchoring in a mooring field and need to control your swing room, deploy the primary as above and attach the secondary at the bow. Drive the boat forward at a 45 degree angle to the primary. Once in line with the primary deploy the secondary

and allow the elements to push you back. Increase astern to 1500 rpm to drive in the secondary. Snorkel over the anchor to ensure a good hold.

- There are a couple of spots in the BVI where it is necessary to deploy both a bow and stern anchor, thus holding the yacht bow or stern into the wind. Set your primary first, then for ease use the dinghy to drive the secondary out to deploy and set by pulling the rode taught.

Weighing anchor:

- Using the already established communication system, slowly motor the yacht forward toward the anchor. When the chain becomes slack the helmsman should go into neutral and increase throttle to 1400, the bowman takes up the slack on the windlass. As the chain starts to tighten the helm needs to start to motor towards the anchor until the chain once again slackens. Again the bowman takes up the slack on the windlass. Repeat this process until the anchor is back on the bow roller. Once the anchor is clear of the water be careful not to let the anchor swing into the boat.
- It is important to help the chain flake-out under the windlass, it may otherwise build up and block the windlass.
- The hardest thing the windlass should do is pull the anchor from the bottom. Take care of it and it will do the work for you. Overload it and you will be very frustrated.
- There is a high amperage fuse that will blow if the windlass gets overloaded. The fuse is located on the starboard side of the salon, behind the corner aft cushion. There are two large fuses next to each other; the anchor windlass fuse is the one on the right, the inner side.
- Ensure that the windlass breaker on the 12v panel is switched on, and that the green light is not illuminated. If it is illuminated, this indicates that the fuse is NOT blown, and that the yacht battery power is too low to run the windlass. Please run the engine @1500 rpm for 15 min, and try again.
- You can tell if the fuse is blown by the tab that pops up. Compare the fuse you have removed with the one in the chart table.
- To replace, first turn windlass switch off, pull the blown fuse straight out and replace with the new one that is located in the chart table.

Before replacing the fuse, however, ensure that the windlass breaker on the 12v panel is switched on, and that the green light is not illuminated. If it is illuminated, this indicates that the fuse is NOT blown, and that the yacht battery power is too low to run the windlass. Please run the engine @1500 rpm for 15 min, and try again. If the



windlass still refuses to operate, please call horizon.

Manual operation of the windlass



If you lose power to your windlass, start the engine and give it some revs, to make sure you have not just got a low battery voltage. Then make sure the windlass breaker with the anchor icon is in the 'on' position on the 12 volt panel. If there is still no power, check the location of the windlass fuse and make sure this has not tripped out. If you still have no power, you can operate the windlass manually.

To drop the anchor, secure the windlass handle into the central hole on the side of the windlass.

Pull back on the windlass handle to loosen the wing nut.

Your anchor is now ready to drop.

Remove the safety line or safety pin, and push the anchor over the bow, keeping hands and feet clear. Control the rate the chain pays out by tightening or loosening the wing nut with the handle. When you have paid out sufficient chain – 5 to 8 times the water depth, push the handle forward to tighten the wing nut. Increase revs to 1500 rpm, to set the anchor. If you drag, pay out more chain, and re-try 1500 rpm in reverse. When the anchor is set, fit the snubbing line, and cleat it off, then release the chain on the gypsy as above, so that the load is taken up on the snubbing line.

10. Picking up a mooring buoy

- Ensure the dinghy painter is tied off short on the bow or amidships and is clear of the prop.
- Approach the mooring buoy, keeping the bow into the wind or current, whichever prevails.
- Have a crew member on the bow to pick up the mooring pennant with the boat hook.
- The bowman will direct the helmsman to the mooring, using the already established non verbal communication system. Once at the mooring, inspect the buoy and pennant for any signs of wear and tear; if you are unsure about the structural soundness of a mooring buoy, choose another location to moor up.
- The bowman should prepare a line to a bow cleat to slip through the eye of the mooring pennant. This line is then shortened and brought back to the same cleat.
- Once set your mooring buoy will be attached either on the port or starboard cleat and the yacht will be head to wind. Remember to centralize the wheel and lock in place to avoid the yacht sailing around the buoy.
- Next attach a second back up line to the mooring. Attach a line from the opposite bow cleat and if possible attach it directly to the mooring buoy. It is always easier to do this from the dinghy. Do not try to make the lines of equal length, the first line should be taking all the weight of the boat.
- To depart, release the backup line first. Slowly motor the boat forward to create slack, release the line from the cleat and allow the pennant to slip from the line into the water. Fall back with the wind or current, and be careful not to foul your prop on the pennant.
- **Remember to tie your dinghy away from the stern whenever you are maneuvering in close quarters.**

11. Bilge Pumps

Your yacht is equipped with one manual and two electric bilge pumps. The primary electric pump is automatic. The secondary electric pump is operated by a switch on the 12v panel. The manual pump is located in the cockpit by the port side helm seat and its operation will be demonstrated to you during your briefing.




12. Fresh water system

State of Play is equipped with two water tanks with a capacity of 210 gallons split between the two.

Before filling the tanks let the water run from the hose for a while before placing the end into the filler. The filler holes are located by the anchor locker and at the port transom. Please ensure that the correct fillers are used, NOT the holding tanks or the diesel fill.

To use the fresh water system, turn on the fresh water breaker on the 12v panel and open a faucet. When the tank runs out of water the pump will run at high speed and the faucet will start to cough air. As soon as you hear the pump running continuously, check to see if anyone is using water. If not, switch off the pump immediately to prevent the pump from drawing more air into the system or the pump overheating.



To switch tanks:

- Switch off pump
- Select the next full tank: the lever is located beneath the sink in the aft head.
- The lever is not 'on' or 'off' – it has two positions (horizontal and vertical) that select one or other tank. After selecting required tank:
- Switch on pump.
- Open cold water faucet at galley and purge system of air, approx. 45 seconds
- Turn off faucet, pump will continue to run until adequate pressure has built up to operate pressure switch to cut the pump out.
- If pump does not cut out, it may be necessary to repeat the purging process and open other faucets
- If you have any problems, call Horizon.

13. Heads

- Nothing is to be put down the head unless it has been digested first, with the exception of 3 sheets of paper.
- Prior to use, move the lever to wet bowl to add water - 4/6 pumps.
- Move lever to dry bowl to pump out waste; this must be done when you are more than 1000 yards off shore.
- Move lever to wet bowl to flush the pan and pipes, 20-25 pulls will keep your heads smelling fresh.
- Move lever back to dry bowl and pump the pan and pipes dry, the lever must be left in dry bowl as leaving it in wet bowl will ingress water.
- Wherever possible please use the heads ashore as this keeps our waters nice and clean.
- **Blocked heads will be cleared at a cost to you of \$120.00 sewage fee, plus a technician's fee of \$60 per hour and the call out fee.**



14. Showers

Your yacht has a hot & cold, fresh-water shower in each head and on the transom. If the engine has been running, the hot water can be very hot – be cautious! In order to use the showers, the fresh-water pump must be activated on the 12V panel. The fresh water pump needs to be on for the shower pump to operate.

Shower drain

To operate the shower-drain pump, switch on the shower drain switch on the 12v panel.

Press the black button on the shower wall to drain the water.

Transom Shower

The valve to the right of the shower head has two functions:

By turning the knob clockwise and counter clockwise you can change the temperature of the water. Be careful. The water can be very hot. Test before showering.

By pushing the valve perpendicular to its long axis you can change the water pressure. In this picture you would move it to the left and right.

To use the shower head simply pull it out and press the lever on the back. If no water comes out, make sure that the 12V water switch is on, that the shower hose is not kinked (access from aft cabin, same side as shower) and that the water pressure valve is in the correct position.



15. Refrigeration

The system on this boat is an upgraded 12v refrigerator. This system is designed to run 24hrs a day if you wish. To ensure that it does not fail there are two things you should do.

- Firstly, keep your batteries charged. If the level goes below 12v the system will malfunction. Refer to section 12 for charging instructions.
- Secondly, do not puncture the cold plate in your fridge! Do not chip at the ice or use any other sharp items in the fridge. If something is frozen to the side of the fridge do not force it away. Pour warm water on it if you need to melt the ice.

There is a thermostat in both the fridges. It is a white dial with numbers on it going from 1-7. Putting 7 at the apex of the dial is the coldest setting. Keep it on this setting until it is too cold. Then you can turn the system down or off if you wish. Or if it is not cold enough...augment the system with ice.

Ask one of our staff for a deck cooler if you would like one for storing your drinks. It will keep the drinks cooler and the refrigeration colder, as people will not be going in it every 5 minutes for a drink.

Please note that we are in the tropics and we cannot guarantee that items will remain frozen when placed in the fridges and that fruit, vegetables and other fresh produce may have a shortened shelf life.



Fridge drain button

16. Propane and stove

The propane tank locker is located under the helm seat on the port side.

To use:

- Turn the LPG switch on the 12v panel. This opens the solenoid on the tank.
- To light, turn the knob you want 90 degrees anticlockwise, push the knob in and light the burner using the igniter button.
- Hold the knob in for 10-15 seconds, then release. Make sure that the flame goes all the way around. Reduce any wind that may hinder this.
- If you cannot get it to light, check the manual shut offs - there are two. One on the propane tank itself and one in the cupboard to the right of the stove. Make sure these are both open and try again.



The 12v solenoid system is USCG approved device. You do not need to shut any manual valves unless you wish.

All of our yachts are fitted with propane detectors. The propane 'sniffer' has been placed in the bilge (propane is heavier than air and so will sink into the bilge). The detectors are sensitive to several types of gas and will trigger the alarm. The alarm can also be triggered if there is moisture in the bilge. If the alarm sounds it does not necessarily mean that the propane system is leaking, so don't panic!!

In the event that the alarm goes off follow these steps:

- Close the valve on the propane tank.
- Check the stove and surrounding area for propane smell.
- If detected, open up the bilges and hatches. Point the boat downwind and use the manual bilge pump to pump out the bilges.
- Call Horizon immediately

Under no circumstances should you use the electrical bilge pumps or any other electrical system if you suspect a gas leak.

17. BBQ

- When using the BBQ, tie your dinghy off at the side of the yacht, not off the stern
- Never use the BBQ while sailing
- Never use the BBQ on a dock
- Never change propane tanks when using the BBQ
- Make sure someone is always tending the BBQ when hot
- Call us if you have too much food



18. Fire Safety

Prevention is the best answer to fire safety.

- Always switch off the safety solenoid when stove is not in use
- Never leave the stove or oven burning unattended.
- Never change propane tanks whilst barbecuing.
- Never smoke below decks.
- Never smoke when changing propane tanks.
- Safely store any flammable liquids (for example charcoal lighter fuel).
- Keep matches away from children.



Engine compartment fire:

In the event of a fire in the engine compartment use the fire extinguisher positioned closest to the companionway hatch steps and position the mouth of the extinguisher to the fire hole.

- Pull the yellow key out
- Press down on the red button until all the contents of the extinguisher have been discharged.
- Do not open the engine compartment even if you think the fire has been extinguished, dying embers can easily be re-ignited by a fresh supply of oxygen.

Open fire:

- Pull out the yellow safety tab.
- Point the extinguisher at the base of the fire and press down on the red button to discharge contents.
- Generously cover the base of the fire and surrounding area to ensure the fire is under control and cannot spread. Continue discharging extinguisher until the fire is out.





Galley fire:

- Take the fire blanket out of its container. Read the instructions for use carefully.
- Ensure hands and limbs are protected from the fire by the blanket.
- Carefully lay the blanket over the fire, laying the blanket away from you and keeping yourself protected at all times from the flames.
- Once in place leave the blanket until all heat has gone from the scene of the fire, this way you can be sure that the fire has definitely gone out and will not re-ignite.

19. Dinghy & Outboard

The driver of the dinghy must be over 18, and must at all times be wearing the kill cord. Never operate the dinghy under the influence of alcohol or drugs.

- Always tow your dinghy on a short line while motoring and a long line while sailing, always tow with the engine leg up as it gives you an extra half knot.
- Most of the time it is fine to leave the outboard on the dinghy, but if conditions are very rough, the outboard needs to be mounted on the push-pit.
- When going ashore for an evening's entertainment allocate a dinghy captain, someone who will bring the whole crew back to the boat safely, allowing the rest of the crew to enjoy various local cocktails and concoctions.
- To start the engine, lower the motor into the water using the lever on the starboard side of the engine. The lever position corresponds to the motor position, up and fwd for towing and back and down for driving. Check you are in neutral and **the safety cord is in place**. For starting an engine that has been at rest for 3 or more hrs use the choke. Pull the choke out, and set a few revs with the throttle. Do not twist the throttle trying to prime the engine. You will only flood it. Face the engine and pull the start cord and push the choke back in as soon as it runs. If it runs for a second but cuts out, try again without the choke.
- To stop the engine, press the button on top of the kill cord, or pull the kill cord out.
- Keep the kill cord with you to prevent anyone from borrowing it. You have been provided a dinghy lock and cable. Use them.
- Do not drag the dinghy onto a beach; anchor it off or put it on a dock with a stern anchor to prevent damage from going under or hitting the dock.
- Do not speed in and around other yachts, speeding fines have been introduced.
- At night an all round white light must be displayed along with red & green side lights, and it is always a good idea to have a flashlight with you, to show the way, and warn other vessels of your presence.
- Wear the life preservers provided in the cockpit lockers when in the dinghy.
- **GAS to OIL ratio, 1 Gall = 3 ounces.**



20. The Generator



State of Play is fitted with its own generator which will run the 110v outlets, the air conditioning and will also charge the batteries in place of the engine. The generator is located behind the back compartment in the port aft cabin

The generator is self-monitoring and therefore no checks need to be performed on a daily basis. If there is something wrong the

generator will simply not start, or shut itself down if it is already running.

To start the generator:

- Make sure the 110v systems, including the air conditioning units, are off prior to starting the generator.
- Ensure that you have switched from shore power to generator power using the selector switch located above the 12v panel.
- Press the 'on/off' button and you will see the start panel light up. Press the 'start' button and hold it until you hear the generator start up.
- Allow the generator to warm up for 5 minutes and then gradually load up the system, adding one load every 2 minutes.



- **Note that the generator can take a maximum of 28 amps. There is a gauge which tells you how much load is on the generator, make sure that you do not exceed 28 amps.**

Stopping the generator

- Turn off all 110v systems
- Press the 'on/off' button and the generator will close down.

21. Air conditioning



The air conditioning breakers should be turned on **after** the generator has been running for 5 minutes (or once the boat is plugged into shore power) and the breakers should be shut **off** before stopping the generator or unplugging from shore power.

Ensure the companionway and all hatches are closed; otherwise the compressors will freeze up.

Starting the air conditioning:

- Switch on the 12v main breaker first.
- Switch on the required units.
- Each of these units also has an individual control which allows users to alter the settings for the individual units.

Using the unit control panels:



- Switch the remote units on using the 'mode' button. Ensure that you are operating in the 'cool' mode. Press the mode button until the cool option is selected.
- Set the temperature using the '+' and '-' controls.
- The units will work best if the minimum temperature is set no lower than 63 degrees. Set it below this and you risk frosting up the unit and causing it to shut down. Ensure that all hatches are closed when using the air conditioning.
- The remote panel will automatically display the ambient temperature.
- Control the fan strength using the 'fan' button.
- Switch the units off by pressing the 'mode' button.